

TempCheck3

Disposable Thermograph like Strip Chart

TempCheck3 is a reliable and economical electromechanical disposable temperature recorder for all transport applications. TempCheck3 is powered by a high torque quartz engine and displays time and temperature on pressure sensitive paper in Celsius and Fahrenheit.



TEMPCHECK3

Traceability:

The TempCheck3 model has the same serial number for the Thermograph and for the graphic chart (Strip Chart), avoiding any problems with adulterations.

Security Seal:

If there is any attempt to remove the security seal, the word "VOID" will appear on the seal and on the box.

Verification / Support:

MaxiTrack offers, at no cost to the user, a post-trip support service. Simply send the recorder to our Laboratory so that we can verify the accuracy against our NIST / USA trackable standards.

Recycling:

The TempCheck3 model is disposable and single use. Please contact our Technical Support for instructions on the proper disposal of these units.

Note: Boxes with 24 units.

TempCheck3 Specifications	
Run Time Options	SKU #8098: 7 days, SKU #8095: 16 days, SKU #8096: 30 days, SKU #8097: 60 days
Operating Range	-13° to +95°F (-25° to +35°C)
Accuracy	±2°F (±1°C)
Thermal Sensor	Bi-metal coil
Drive Source	Solid state quartz-controlled motor
Power Source	One AA 1.5 volt carbon zinc battery, mercury free
Size	4.75 in (L) x 4.25 in (W) x 2.5 in (H) 12.1 cm (L) x 10.8 cm (W) x 6.4 cm (H)
Weight	0.46 lbs. (0.2 kg)
Simple Starting Procedure	1. Fill in documentation tag 2. Peel off top tag 3. Pull and remove start tab
Wall mounting options	Self-adhesive double-sided foam tape
CE Certified	Yes
Carton	
Quantity	24 units
Weight	13 lbs (5.9 kg)
Size	15 in (L) x 11 in (W) x 10 in (H) 38.1 cm (L) x 27.9 cm (W) x 25.4 cm (H)