


MAXI  TRACK

# GLOBAL REACH


*local knowledge*



# TECHNOLOGICAL SOLUTIONS IN MANAGEMENT OF TEMPERATURE AND HUMIDITY

maxitracksensors.com

- **Complete System:**
- Hardware
- software
- Technical services



Solutions for Temperature and  
Relative Humidity Management

## In-Transit-2 System

# WHERE TO USE?

## IN-TRANSIT-2 CENTRALIZED MANAGEMENT SYSTEM

[maxitracksensors.com](http://maxitracksensors.com)

### Applications:

- Transport of Medicines, Foods or thermo-sensitive products.
- Laboratory ovens and refrigerators
- Data Centers / CPDs
- Climatized Environments
- Refrigerators / Exhibitors
- Storage of Vaccines and Medicines
- Cold Chambers / Food
- Diagnostic Imaging Sectors
- Pharmacies and Warehouses
- Surgical Centers
- Clinical Analysis Laboratories and Air-conditioned Environments in General
- Industrial Engines and Machinery
- Construction



## In-Transit-2 System

# WHICH IS?



[maxitracksensors.com](http://maxitracksensors.com)

The In-Transit-2 Solution is a 3G (wireless) transmission system developed for the **online monitoring** of temperature, humidity (among many other parameters), in the most varied environments such as **refrigerated transport (land, air or sea), warehouses, pharmacies, warehouses, greenhouses, refrigerators, cold rooms, etc. Continuously logs (and Online) and sends alerts** via e-mail and SMS whenever something is not in ideal conditions, thus avoiding considerable losses in the quality of the products, thus avoiding possible financial losses.

- **Technology:** 2/3G transmission with worldwide coverage
- **Easy Installation / Plug & Play:** Just affix and press the START button
- **Security:** EEPROM type memory (non-volatile)
- **Ease:** Long-lasting built-in battery
- **Accuracy:**  $\pm 0.5$  °C |  $\pm 3.0$  %UR\*
- **GPS:** Geopositioning and Electronic Fences



# IN-TRANSIT-2 SYSTEM | OVERVIEW



# IN-TRANSIT-2 SYSTEM | MODELS



Solução em nuvem  
**CLOUD COMPUTING**

## IN-TRANSIT-2 SYSTEM

# TECHNICAL SPECIFICATIONS

[maxitracksensors.com](http://maxitracksensors.com)

### WEB-type Temperature and Relative Humidity Management System

Management software runs via Browser:  
Internet Explorer, Mozilla Firefox or Google Chrome.

- **Storage of Registered Data in the Cloud:**
- It does not require the use of servers or local computers;
- Reports: Graph and Table format;
- Maximum capacity of sensors in a Single System or Gateway: unlimited;
- Alarms: via email or SMS (with individual adjustments per sensor);
- Alarm Modes: MIN and MAX;
- Automatic recording of measurement data with configurable recording intervals;
- Pause/record function for each sensor;
- 2 / 3 G System: It has universal transmitter and does not depend on local SIM chip.
- Number of Users: unlimited (admins and users);
- Data Storage: indefinitely.

## IN-TRANSIT-2 SYSTEM

# SYSTEM REQUIREMENTS

[maxitracksensors.com](http://maxitracksensors.com)

### **Minimum requirement – In-Transit-2 line:**

Internet Explorer, Mozilla Firefox or Google Chrome – The client's network or server will not be used.

### **Powering the InTransit-2 Loggers:**

Internal rechargeable batteries (reusable version). No need for external power supplies.

### **Sending alarms by email / SMS:**

In order for the InTransit-2 line type 2 / 3G Loggers to update the reports on the Galileo / WEB Portal and send Temperature and/or Humidity alerts via email and SMS, it is necessary to have a local cellular signal.

### **Infrastructure needed:**

Presence of Cellular signal and internal battery with good charge level.

\* Consulte nossa Engenharia para instalações em áreas Rurais ou Remotas



## IN-TRANSIT-2 SYSTEM

# SYSTEM

maxitracksensors.com

Unlimited number of sensors, **managed by name**, area or any other type of internal numbering (eg user-defined TAGs).

### **Security / memory system:**

In situations of use in transport and in shadow areas (no 2 /3 G signal) the InTransit-2 registers will continue with the recordings in their internal memory.

As soon as the signal is re-established, the information accumulated in memory will be synchronized and updated in the Portal.



# IN-TRANSIT-2 SYSTEM


# SYSTEM

maxitracksensors.com

## Galileo Monitoring Portal

### Supervisory Software with Graphical interface, Numerical Table and statistical information

- Runs on any operating system (via Browser);
- Accessible via internet 24 hours a day x 7 days a week;
- It has numerous measurement analysis tools;
- "Open" type system, allows modifications according to future customer demands (Customizable);
- Integration feature in "API" format (optional);
- Secure access: 100% WEB / via internet and fully encrypted.



**MAXI TRACK**  
maxitracksensors.com

# IN-TRANSIT-2 SYSTEM

# SYSTEM

maxitracksensors.com

- Geopositioning and configuration of Electronic Fences (Geofences)
- Status of each device by Location
- Flight Mode: Activation of 'Airplane Mode' via the front button or via Portal.

The screenshot displays the MAXI TRACK web application interface. At the top, there is a search bar with the text "ID del dis..." and a "Buscar" button. To the right, there are filters for "Filtro claro" and "°C", and a language dropdown set to "Es...". Below the search bar is a sidebar menu with options: "Visión general", "Dispositivos", "Configuración", "Informes", "Gestión de", and "Apoyo". The main area features a map of South America with a red location pin in São Paulo, Brazil. A popup window over the map displays the following data: "Temperatura 26.1 °C", "Hora 18:18 21/05/19", "ID del dispositivo T10C0009", "Batería 77%", and "Ubicación São Paulo Sao Paulo Sao Paulo Avenida Doutor Jesuino Maciel". To the right of the map is a circular gauge showing a 50.00% split between green and blue, and a list of device statuses: "Ocioso 1", "En tránsito 1", "Alarma 0", "Desconectado 0", and "Modo vuelo 0". Below the map is a table with columns: "ESTADO", "EMPEZADO", "ID DEL DISPOSITIVO", "DESTINO", "RECEPTOR", "BIENES", and "OPERACIÓN". The table contains one row of data: "21:47 14/05/19", "T10C0009", "Belo Horizonte", "Torrent Pharma", "Vacina B9D", and an eye icon.

## IN-TRANSIT-2 SYSTEM

# APP

[maxitracksensors.com](http://maxitracksensors.com)

The **Galileo Monitoring Portal** user has the exclusive App that can be used on any type of Tablet or Smartphone.



***Monitoring in the palm of your hand, wherever you are!***

Disponível para compra em:



## IN-TRANSIT-2 SYSTEM

# ACQUISITION OR LEASE

[maxitracksensors.com](http://maxitracksensors.com)

In addition to the traditional Purchase/Acquisition modality, **MaxiTrack** offers its customers the option of **Lease**.

See the advantages:

- Fractionation of the Initial Investment Value over the years;
- Ease of expanding the system and reducing bureaucracy;
- Fair and attractive monthly fees;
- Possibility of adding Preventive Maintenance to the contract;
- Possibility of adding Annual Calibration to the contract (in-place option);
- Permanent Warranty for all system components (for the duration of the contract);
- System annual fee included in monthly fees;
- Replacement of components that may present a factory defect quickly and at no cost;;



**MSA - MaxiTrack Service Agreement**

**MAXI TRACK**  
[maxitracksensors.com](http://maxitracksensors.com)



# CUSTOMERS

[maxitracksensors.com](http://maxitracksensors.com)



# CUSTOMERS

maxitracksensors.com



**MAXI TRACK**  
maxitracksensors.com

# MEASUREMENT AND MONITORING

.....

Talk to our sales consultants and also learn about our **lines of data loggers, thermo-hygrometers and monitoring systems for transport.**



Disposable



Bluetooth



Infra-red



GPS Transport



Temperature and Humidity



Thermo-Hygrometer





# RBC-INMETRO CALIBRATION AND THERMAL STUDIES

.....

## Temperature and Humidity Calibrations

Our entire line of equipment can be supplied already calibrated.

- **Accredited by RBC-INMETRO;**
- **Tracked by RBC-INMETRO;**
- **On-site calibration [equipment, cameras, vehicles, etc.].**

Calibrations can be provided for both **new equipment** and **annual recalibrations**.

## Mapping, Qualification and Validation Services

- **Specialized Technical Service of Thermal Mapping;**
- **Specialized Technical Service for Equipment Qualification;**
- **Specialized Technical Service for the Validation of Systems and Production Areas;**



# CONTACTS

---



**Sales:**

[info@maxitracksensors.com](mailto:info@maxitracksensors.com)

[www.maxitracksensors.com](http://www.maxitracksensors.com)



**Technical Assistance and Support:**

[eng@maxitracksensors.com](mailto:eng@maxitracksensors.com)